


Alternator with Universal Ignition Switch.




DLM 05-29-02
 Changed DF to D+ on Alternator
 12-01-02


Note: To solenoid and or elect
 choke on carb if equipped.

Basic System with Alternator
 REV 5-23-04

Generator with Universal Ignition Switch.



Alternator with Toggle Switch & Push Button.



DLM 05-29-02


Changed DF to D+ on Alternator
12-01-02

Note: To solenoid and or elect
choke on carb if equiped.

Basic System with Alternator

Rev. 5-02-03

Generator with Toggle Switch & Push Button.



DLM 05-28-02

Note: to solenoid or elect choke on carb if so equipped

Basic System with Generator

Rev. 5-2-03